

18. Brief instructions for installation


These brief instructions do not replace the installation and operating manual.


Read this installation and operating manual carefully and, most importantly, follow all warnings and safety instructions. This will ensure that you can install the product safely and optimally.





19. Connection diagrams and functions of the DIP switches





DIP switches on the carriage	ON	OFF 🔐
0 L N S 2 46	Automatic closing function activated	Automatic clos- ing function deactivated
0 1 N 2 8 8	Partial open- ing activated / Lighting function deactivated	Partial opening deactivated / Lighting function activated
0N 12 14		
Ο Ν ω 4		

DIP switches on the ceiling control unit	ON	OFF 🛺
ON	"Conex" additional circuit board	"Conex" additional circuit board
1234	Button 1 defined door OPEN	Button 1 pulse sequence
	Button 2 defined door CLOSE	 Button 2 lighting function / partial opening
ON 1234	Door status dis- play relay is acti- vated during door movement and if the door is not closed	• Lighting function
	 Door status dis- play 	
ON 1234	No function	No function
ON 1234	No function	No function

46900V024_Rev-B_US-EN 71